



INSTALLATION NOTES:

Completely remove old pivot assembly

Installation Sequence:

PIVOT SHAFT, torque to spec.
 POSITIONING SHIM
 8002562, Tensioner Assembly with bushings
 (Lubricate bushings before installing)
 PRELOAD SPACER
 CAP/SPRING assembly
 SECURING SCREW, torque to spec.

THIS DOCUMENT IS THE PROPERTY
 OF PAXTON PRODUCTS AND IS
 FURNISHED ON THE CONDITION
 THAT IT IS TO BE USED ONLY BY
 PAXTON CUSTOMERS FOR
 INTEGRATING PAXTON
 EQUIPMENT. THIS DOCUMENT
 MAY BE USED BY CUSTOMERS TO
 CREATE THEIR OWN EQUIPMENT
 DOCUMENTATION. OTHERWISE
 THIS DOCUMENT IS NOT TO BE
 USED IN ANY SHAPE OR FORM TO
 CREATE DOCUMENTS, PARTS, OR
 EQUIPMENT.

PAXTON
PRODUCTS

10125 Carver Road Phone: (800) 441-7475
 Cincinnati, OH 45242 (513) 891-7474
www.paxtonproducts.com

**PIVOT ASSY, REPLACEMENT, AT SERIES
 SPRING LOADED CAP, SHAFT, & PARTS**

DATE
 3/31/2010

INVENTOR DWG No.

CS-8002565