



INSTALLATION NOTES:

Completely remove old pivot assembly

Installation Sequence:

- PIVOT SHAFT, torque to spec.
- POSITIONING SHIM
- 8002562, Tensioner Assembly with bushings
(Lubricate bushings before installing)
- PRELOAD SPACER
- CAP/SPRING assembly
- SECURING SCREW, torque to spec.

THIS DOCUMENT IS THE PROPERTY OF PAXTON PRODUCTS AND IS FURNISHED ON THE CONDITION THAT IT IS TO BE USED ONLY BY PAXTON CUSTOMERS FOR INTEGRATING PAXTON EQUIPMENT. THIS DOCUMENT MAY BE USED BY CUSTOMERS TO CREATE THEIR OWN EQUIPMENT DOCUMENTATION. OTHERWISE THIS DOCUMENT IS NOT TO BE USED IN ANY SHAPE OR FORM TO CREATE DOCUMENTS, PARTS, OR EQUIPMENT.



10125 Carver Road Phone: (800) 441-7475
Cincinnati, OH 45242 (513) 891-7474
www.paxtonproducts.com

**PIVOT ASSY, REPLACEMENT, AT SERIES
SPRING LOADED CAP, SHAFT, & PARTS**

DATE 12/5/2013

INVENTOR DWG No.

CS-800-Pivot