

Paxton Replacement Filter Elements

MODEL # 8005550-2

10 micron 800 cfm, maximum flow

| Item Number | 8005550-2 | | |
|----------------------------------|--|-------------------------|--|
| Description | Replacement Filter Elements, 2 pack | | |
| Fits blowers | XT-500, AT-700 | | |
| Efficiency | 98% @ 10 micron, nominal | | |
| Maximum Flow Rate | 800 scfm | 23 m³/min | |
| Maximum Operating Temperature | 185°F | 85°C | |
| Initial Operating Pressure | 1.5° H ₂ O | 38 mm H ₂ O | |
| Maximum Pressure Drop | 12° H ₂ O | 305 mm H ₂ O | |
| Media | Hi-Flow Synthetic, 60H: Hydrophobic, water repelling, non-absorbing, oil resistant | | |
| Material of Construction | Steel, powder coat finish, corrosion resistant | | |
| Weight, each | 2.5 lbs | 1.1 kg | |
| Dimensions | | | |
| Length Diameter | 10 in 10 in | 254 mm 254 mm | |
| | | | |



Related Components

| Item Number | 800 | 5548 | 8005 | 5564 |
|---|---|----------------------------|---|------------------|
| Description | Hi-Flow Synthetic Filter with Housing 800 cfm @ 10 micron | | Silencer Cartridge: attenuates noise up to 8 dB | |
| Dimensions Inlet Length Diameter | 4 in 12 1/8 in 10 in | 102 mm 308 mm 254 mm | 5 3/4 in 5 3/4 in | 146 mm 146 mm |
| Weight | 8 lbs | 3.6 kg | 2 lbs | 0.9 kg |

Recommended Replacement Frequency

| Paxton part | 1 or 2 shifts/day operation | 3 shifts/day operation | |
|--------------|--|---------------------------|--|
| Belts | 12 months | 6 months or 4000 hours | |
| Belt Springs | 12 months | 6 months or 4000 hours | |
| Tensioners | 24 months | 12 months | |
| Filters | Filters must be changed as often as needed to maintain blower or system performance as measured by increased pressure drop across the filter. The filter must be changed if the pressure drop exceeds 10" of water column. Filter change frequency will vary widely based on environmental and atmospheric conditions. Minimum recommended filter change frequency is every 12 months for 1 or 2 shift/day operation; and every 6 months for 3 shift/day operation. | | |

